

Module System

Oxygen MODULE

Suction MODULE

Combi MODULE

Interface MODULE

CPAP MODULE






Instructions for use



Contents

1. Overview	3	9.1 CPAP function	32
1.1 Markings on the device	4	9.2 Operation	32
2. Description of device	6	10. OMNIVAC secretion aspiration system	35
2.1 Intended use	6	10.1 Starting work	36
2.2 User qualification	6	10.2 Aspiration	36
2.3 Combination options	7	10.3 Stop aspiration	38
2.4 Storage	7	11. Hygiene treatment	39
3. Safety instructions	8	11.1 Preparing the OMNIVAC secretion aspiration system	39
3.1 Safety instructions	8	11.2 Cleaning, disinfecting and sterilizing	40
3.2 Contraindications	11	11.3 Assembling the OMNIVAC secretion aspiration system	41
3.3 Side effects	12	12. Function check	42
4. Assembly	13	12.1 Intervals	42
4.1 Assembling the modules	13	12.2 Check filling	43
4.2 Connecting oxygen supply	14	12.3 Test leaktightness	44
4.3 External oxygen connection	16	12.4 Checking inhalation	45
4.4 Assembling breathing station	17	12.5 Checking aspiration	46
4.5 Assembling the bubble humidifier	17	12.6 Checking oxygen flow	47
4.6 Assembling the OMNIVAC secretion aspiration system	18	12.7 Testing the pressure gauge	47
4.7 Assembling the CPAP valve	20	13. Troubleshooting	48
5. Oxygen MODULE	21	13.1 Adjusting pressure gauge	49
5.1 Inhalation function	21	14. Servicing	50
5.2 Operation	22	14.1 Intervals	50
5.3 Stop inhalation	23	14.2 Scope of servicing	50
6. Suction MODULE	24	14.3 Disposal	51
6.1 Vacuum/aspiration function	24	15. Scope of supply	52
6.2 Operation	24	15.1 Standard scope of supply	52
6.3 Stop aspiration	25	15.2 Accessories	54
7. Combi MODULE	26	15.3 Replacement parts	56
7.1 Inhalation function	26	16. Technical data	57
7.2 Vacuum/aspiration function	27	16.1 Determining oxygen concentration	58
7.3 Inhalation - operation	27	16.2 External oxygen output	61
7.4 Stop inhalation	28	16.3 Oxygen output, inhalation	62
7.5 Aspiration - operation	29	16.4 Aspiration performance	62
7.6 Stop aspiration	30	17. Warranty	64
8. Interface MODULE	31	18. Declaration of conformity	65
8.1 Coupling/oxygen connection function	31		
8.2 Operation	31		
9. CPAP MODULE	32		


1. Overview



Key






- 1 Oxygen inlet with nonreturn valve (not seen)
- 2 Display
- 3 Oxygen outlet
- 4 Toggle switch
- 5 Regulator dial
- 6 Vacuum connection
- 7 Inhalation connection
- 8 External oxygen connection
- 9 Vacuum on/off switch
- 10 Pressure measurement tube connection
- 11 CPAP valve connection

1.1 Markings on the device



ID plate for MODULES

1	SN	Serial number of device
		Date of manufacture
		Type of gas: O ₂
	CE 0197	CE symbol (confirms that the product conforms to the applicable European directives)
		Permitted inlet pressure 2.7 - 6 bar O ₂
		Follow instructions for use
Other markings		
2	Inhalation Débit	Inhalation connection
3	Suction Aspiration	Aspiration connection

4		Oxygen inlet and outlet
5		Oxygen outlet
6		O ₂ outlet for CPAP
7		Permitted inlet pressure 2.7 - 6 bar O ₂
8		Service label: indicates when the next service is required.

2. Description of device

2.1 Intended use


Intended use	Oxygen MODULE	Suction MODULE	Combi MODULE	Interface MODULE	CPAP MODULE
To increase the percentage proportion by volume of oxygen in inhaled air	X	–	X	–	X
To create a vacuum to enable relatively large accumulations of blood, mucus, saliva etc. as well as viscous and solid pieces of food to be extracted from the oral cavity, the pharyngonasal cavity and the bronchial system with the aid of a secretion aspiration system	–	X	X	–	–
To pass the oxygen supply on to other devices via the coupling connection	X	X	X	X	X
To facilitate an external oxygen supply via the coupling connection	X	X	X	X	X
To supply the CPAP valve (Boussignac CPAP valve for CPAP MODULE) via a regulatable oxygen flow rate to achieve and display a desired therapy pressure	–	–	–	–	X

2.2 User qualification


The modules may only be used and operated by people with the following qualifications:

- medical training and instruction in non-invasive ventilation technology.
- instruction in how the modules work.

2.3 Combination options



You can use modules individually or connected in series of up to three modules.



Another option is to connect up to three modules to the MEDUMAT ventilation device.



Always operate only one module or one Medumat at a time. If you use modules simultaneously, it is possible the supply of O₂ will be inadequate.

2.4 Storage

If a module is not used for an extended period, we recommend the following procedure.

1. Perform a hygiene treatment (see “11. Hygiene treatment” on page 39).
2. Store the module in dry conditions.

3. Safety instructions

3.1 Safety instructions

For your own safety and that of your patients, and in accordance with the requirements of directive 93/42/EEC, observe the points below.

General

- Please read these instructions for use through carefully. They are a constituent part of the device and must be available at all times.
- Read carefully through the instructions for use for the accessories used. They form part of the accessories.
- Before you work with the modules, you must have understood how to operate them.
- Follow the section entitled “11. Hygiene treatment” on page 39 to prevent an infection or bacterial contamination.
- Do not use the modules in a toxic or dusty atmosphere.
- Use the modules only in the permitted ambient conditions (see “16. Technical data” on page 57).
- Use only the accessories mentioned in Section 15.
- Use the modules only for the intended purpose described (see “2.1 Intended use” on page 6).
- You may never operate more than one device simultaneously, otherwise it is impossible to guarantee compliance with the specified



technical data. For the same reason, you may not operate the modules whilst oxygen is being tapped off for external devices.

- The modules are not suitable for hyperbaric (pressure chamber) use.
- Please monitor that the devices are functioning perfectly during use, as well – especially if cylinder pressure is dropping.
- In the event of a device failing, you need to have an alternative to hand, e.g. for aspiration, the MANUVAC manual aspiration pump in case the Suction MODULE or Combi MODULE breaks down.

Accessories/repairs

- Have repair work performed only by the manufacturer, WEINMANN Emergency, or authorized staff.
- If third-party items are used, functional failures and restricted fitness for use may result. Biocompatibility requirements may also not be met. You should be aware that in these cases, any claim under warranty or liability will be void if neither the accessories recommended in the instructions for use nor genuine replacement parts are used.
- Protect rubber parts from UV light and prolonged exposure to sunlight, otherwise they may become brittle and friable.

Oxygen



In combination with flammable substances (grease, oil, alcohol etc.), highly-compressed oxygen can lead to spontaneous explosive reactions.

- Keep the devices and all screwed connections absolutely free of oil and grease.

- It is essential to wash your hands before working on the oxygen supply.
- Smoking and naked flames are strictly prohibited in the vicinity of fittings which carry oxygen.
- During assembly and when changing cylinders, tighten all screwed connections on the oxygen supply and on the pressure reducer only by hand. Under no circumstances may you use tools. Excessive tightening damages the threads and seals and then leads to leaks.
- Secure oxygen cylinders so they cannot tip over. If the cylinder falls on the pressure reducer or the valve, these could be torn off, triggering a violent explosion.
- Ensure that the respiratory gas is adequately temperature-controlled. Excessively warm or cold gas may harm the patient. Please also observe the permitted ambient conditions (see "16. Technical data" on page 57).

Important

- Always open the cylinder valve slowly to prevent hammering on the fittings.
- Do not empty cylinders completely, otherwise damp ambient air may penetrate and lead to corrosion.

Inhalation

- If you use WEINMANN Emergency inhalation masks, a dangerous rise in pressure is not possible.
- However, please ensure that the exhaled respiratory gas can flow away freely.

Aspiration

- Use the Suction MODULE and the Combi MODULE only if you are medically trained and



familiar with aspiration technology. Severe physical injuries can be caused by incorrect use.

- Pay particular attention during aspiration to ensure that no injuries are caused to the patient's oropharyngeal cavities, e.g. to the mucous membranes.
- For bronchial aspiration, work under sterile conditions and use only sterile aspiration catheters.
- Dispose of fluids such as blood and secretions, as well as parts contaminated with these fluids, as per the guidelines in the Federal Health Gazette entitled "Anforderungen der Hygiene an die Abfallentsorgung" [Hygiene requirements when disposing of waste] (published by the Federal Office of Health and obtainable from Carl Heymanns Verlag, Cologne).
- Please ensure that the aspirate bottles are always upright during aspiration, otherwise the ball of the overflow cutout cannot reliably block the outlet.

Important!

CPAP therapy

- The CPAP MODULE is not licensed for inhalation.
- Use the CPAP MODULE only if you are medically trained and familiar with CPAP therapy. Severe physical injuries can be caused by incorrect use.

3.2 Contraindications

Observe the contraindications for the therapies in question. These may include (examples):

- impaired consciousness
- lung diseases requiring intubation

- use of mask impossible
- undrained pneumothorax
- intracranial hypertension.

3.3 Side effects

If the contraindications are taken into account, no side effects are likely in use with normal oxygen.

However, observe the side effects mentioned in the patient information leaflet entitled "Medical oxygen" in the case of

- newborns
- administration of 100% oxygen
- administration of oxygen under elevated pressure.

4. Assembly


If the modules are supplied complete on a LIFE-BASE or LIFE-BASE Mini carrying platform, they are operational and you need not perform any further assembly.

4.1 Assembling the modules


Connecting

1. Release the connection to the oxygen supply (see "Removing an empty cylinder" on page 15).
2. Unscrew the cover of the oxygen outlet from the module.


If you screw the cover back on later, tighten it just hand-tight to prevent damage to the housing.




3. Push the protective ring supplied over oxygen outlet **3**. The protective ring prevents dirt penetrating the housing.



4. Plug the modules together.
The seal is made by the O-ring.





5. Connect any other modules in exactly the same way.




No more than 3 modules may be connected, otherwise it is impossible to guarantee compliance with the specified technical data.

6. Screw the modules and, if appropriate, the MEDUMAT onto the assembly plate from the back as shown in the assembly instructions provided,

or

screw the modules to a solid wall from the back. Please note that screws should protrude no more than 5.5 mm into the modules.




4.2 Connecting oxygen supply




Wash your hands thoroughly before any work on the oxygen supply. Hydrocarbon compounds (e.g. oil, greases, alcohols for cleaning, hand cream or sticking plaster) can lead to explosive reactions if they come into contact with highly-compressed oxygen.

Under no circumstances use spanners or other tools to tighten up the union nuts.



You should always connect the oxygen supply at the extreme left-hand module, as oxygen inlet **1** of all modules is equipped with a nonreturn valve.



The nonreturn valve ensures that the oxygen can get in but cannot get out at this connection.

Oxygen outlet **3** has no non-return valve.

For the same reason, the MODULE which allows connection to an additional external oxygen supply (in this case an Interface MODULE) should always be attached the furthest to the left.

Removing an empty cylinder

1. Close the valve on the oxygen cylinder.
2. Switch on a module. This allows any residual oxygen to escape and the device is depressurized. The screwed connection may not be undone until the pressure gauge on the pressure reducer is displaying "0".
3. Switch the module off again.
4. Undo the manual screwed connection to the cylinder.


Connecting a new cylinder

1. Briefly open the valve on the new oxygen cylinder and close it again. This is intended to blow away any particles of dust.



Point the valve opening away from your body as you do this so that you injure neither yourself nor any other person with any particles which may fly out!

2. Screw the pressure reducer with the corrugated union nut to the cylinder valve. Tighten the union nut hand-tight.
3. Screw the pressure tube with the G 3/8 union nut to the pressure reducer outlet.
4. Screw the other end of the pressure tube to oxygen inlet **1** of the module.



4.3 External oxygen connection

In addition to oxygen inlet **1**, you can use external oxygen connection **8** to tap off or feed in oxygen.

Tapping off oxygen



You may not operate a module at the same time as tapping off oxygen, otherwise the specified technical data will not be maintained.


Feeding in oxygen

You can use the external oxygen feed for example to allow continued working with the modules when the oxygen cylinder is being changed.


Due to the nonreturn valves in oxygen inlet **1**, oxygen should always be fed in at the module fitted on the extreme left.

4.4 Assembling breathing station


Disposable inhalation mask and nasal cannula



The disposable nasal cannula and inhalation masks with or without economy bag are made of transparent plastic. For hygiene reasons, they may only be used for one patient.




1. If necessary, screw union nut **7** supplied onto the corresponding threaded connection of the Oxygen MODULE or the Combi MODULE.




2. When the module is used, plug the tube onto the union nut.


4.5 Assembling the bubble humidifier



1. Unscrew the tank from the top part of the bubble humidifier.




2. Screw the top part of the bubble humidifier onto the corresponding threaded connection of the Oxygen MODULE or the Combi MODULE by hand.




3. Fill the bottom part up to the mark with distilled water (aqua dest.) and screw the tank back on.
4. Push the tube for the breathing station onto the outlet stub of the bubble humidifier.

4.6 Assembling the OMNIVAC secretion aspiration system


The OMNIVAC secretion aspiration system is required for aspiration using the Suction MODULE or the Combi MODULE.



1. Screw the holder for the secretion aspirate bottles to a suitable point.




2. Put both aspirate bottles in the holder.




3. Connect the bottles and the module with the appropriate tubes. Ensure that the bottle with the overflow cutout is connected to the module first.

We recommend fitting a hydrophobic bacteria filter WM 22291 for the exhaust air to prevent secretion and bacteria penetrating the module. Filter WM 22291 is obtainable as an accessory, individually or in sets. It is a disposable item and must be replaced after every aspiration operation.




4. Take the vacuum tube off the module.
5. Cut a piece about 6 cm long off the vacuum tube.
6. Put this short piece of tube onto the side of the filter marked with "TO PUMP".



7. Plug the other end of the short piece of tube onto the vacuum connection of the module.
8. Put the free end of the vacuum tube on the filter.

4.7 Assembling the CPAP valve



1. Connect the CPAP valve to the CPAP module using the connecting tubes.
Ensure that the tubes are guided cleanly so that they do not impede one another.
2. Perform a function check (see "12.6 Checking oxygen flow" on page 47).

5. Oxygen MODULE

5.1 Inhalation function

You can perform oxygen inhalation using the Oxygen MODULE.

Conditions of use

Oxygen inhalation only makes sense in emergency patients who are still breathing spontaneously. This is the case with breathing disorders, for example.



In the event of respiratory failure, inhalation of oxygen is by no means adequate and artificial ventilation will be required here. The pressure of the oxygen during inhalation is not adequate to overcome the resistance of the respiratory tract, so not enough oxygen reaches the lungs.

The patient is supplied with oxygen via an inhalation mask or nasal cannula.

You can also connect the inhalation tube to a ventilation bag to allow ventilation at an increased oxygen concentration.

To prevent mucous membranes drying out in the case of prolonged oxygen inhalation, you can fit a bubble humidifier (see “4.5 Assembling the bubble humidifier” on page 17).

5.2 Operation

Oxygen supply

1. Open the oxygen supply valve **slowly**. The contents pressure gauge now shows cylinder pressure.
2. Calculate remaining operating time, if appropriate (see "Calculating filling level" on page 43).


Method

1. Switch on oxygen inhalation at toggle switch **4**.
2. Regulate the quantity of oxygen coming out infinitely between 0 and 15 l/min using dial **5**. This corresponds to three revolutions of the dial.

The value set is displayed on pressure gauge **2**.

Determine oxygen concentration if necessary (see "16.1 Determining oxygen concentration" on page 58).

3. The device is operational when oxygen can be felt coming out at the inhalation mask.
4. Put the inhalation mask or nasal cannula on the patient. Attach these in position using the head band or ear-hooks.




5.3 Stop inhalation

1. Check the oxygen reserve at the contents pressure gauge of the pressure reducer.
2. Close the oxygen supply valve and wait until the system is depressurized.
3. Turn dial **5** to the left-hand stop (to “zero”). This prevents the pressure gauge being damaged by hammering when the device is switched back on.
4. Switch the module off using toggle switch **4**.
5. Clean and disinfect/sterilize the device and the device parts (see “11. Hygiene treatment” on page 39).
6. Perform a function check (see “12. Function check” on page 42).

6. Suction MODULE

6.1 Vacuum/aspiration function

The Suction MODULE is used to aspirate accumulations of blood, secretions or pieces of food from the oral cavity, nasopharyngeal cavity and the bronchial system.



The OMNIVAC secretion aspiration system is available as an accessory, complete with tubes and two aspirate bottles (see “10. OMNIVAC secretion aspiration system” on page 35).


6.2 Operation

Oxygen supply

1. Open the oxygen supply valve **slowly**. The contents pressure gauge now shows cylinder pressure.

If appropriate, calculate remaining operating time as a function of cylinder pressure (see “Calculating filling level” on page 43).

Method



1. Switch on the vacuum at toggle switch **4**.
2. Close the fingertip regulator and hold the opening of the end-piece closed so that no more air can flow through it.
3. Regulate the vacuum using dial **5**. There are three revolutions of the dial between minimum and maximum.
4. Check the value set at pressure gauge **2**.
5. Now you can aspirate.

Keep checking the filling level of the oxygen cylinder from time to time.

6.3 Stop aspiration

1. Check the oxygen reserve at the contents pressure gauge of the pressure reducer.
2. Close the oxygen supply valve and wait until the system is depressurized.
3. Turn dial **5** to the left-hand stop (to "zero"). This prevents the pressure gauge being damaged by hammering when the device is switched back on.
4. Switch the module off using toggle switch **4**.
5. Clean and disinfect/sterilize the device and the device parts (see "11. Hygiene treatment" on page 39).
6. Then perform a function check (see "12. Function check" on page 42).

7. Combi MODULE

You can use the Combi MODULE to perform oxygen inhalation or aspiration. Oxygen inhalation and aspiration may not be used simultaneously, otherwise oxygen output is reduced during inhalation.

7.1 Inhalation function

Conditions of use

Oxygen inhalation only makes sense in emergency patients who are still breathing spontaneously. This is the case with breathing disorders, for example.



In the event of respiratory failure, inhalation of oxygen is by no means adequate and artificial ventilation will be required here. The pressure of the oxygen during inhalation is not adequate to overcome the resistance of the respiratory tract, so not enough oxygen reaches the lungs.


The patient is supplied with oxygen via an inhalation mask or nasal cannula.

You can also connect the inhalation tube to a ventilation bag to allow ventilation at an increased oxygen concentration.

To prevent mucous membranes drying out in the case of prolonged oxygen inhalation, you can fit a bubble humidifier (see “4.5 Assembling the bubble humidifier” on page 17).

7.2 Vacuum/aspiration function

The Combi MODULE can also be used to aspirate accumulations of blood, secretions or bits of food from the oral cavity, the nasopharyngeal cavity and the bronchial system.




The OMNIVAC secretion aspiration system, complete with tubes, is available as an accessory. There is an example in the adjacent picture.

7.3 Inhalation - operation

Oxygen supply

1. Open the oxygen supply valve **slowly**. The contents pressure gauge now shows cylinder pressure.
2. Calculate remaining operating time, if appropriate (see “Calculating filling level” on page 43).

Method



1. Switch on oxygen inhalation at toggle switch **4**.
2. Regulate the quantity of oxygen coming out infinitely between 0 and 15 l/min using dial **5**. This corresponds to three revolutions of the dial.

The value set is displayed on pressure gauge **2**.

Determine oxygen concentration if necessary (see "16.1 Determining oxygen concentration" on page 58).

3. The device is operational when oxygen can be felt coming out at the inhalation mask.
4. Put the inhalation mask or nasal cannula on the patient. Attach these in position using the head band or ear-hooks.

7.4 Stop inhalation

1. Check the oxygen reserve at the contents pressure gauge of the pressure reducer.
2. Close the oxygen supply valve and wait until the system is depressurized.
3. Turn dial **5** to the left-hand stop (to "zero"). This prevents the pressure gauge being damaged by hammering when the device is switched back on.
4. Switch off the module by setting toggle switch **4** to "**0**".

5. Clean and disinfect/sterilize the device and the device parts (see "11. Hygiene treatment" on page 39).
6. Perform a function check (see "12. Function check" on page 42).


7.5 Aspiration - operation

Oxygen supply

1. Open the oxygen supply valve **slowly**. The contents pressure gauge now shows cylinder pressure.
2. Calculate remaining operating time, if appropriate (see "Calculating filling level" on page 43).

Method

1. Switch on the vacuum at toggle switch **9**.
Maximum vacuum is permanently set to – 0.5 bar and cannot be read off directly on the pressure gauge.
2. Now you can aspirate.
Keep checking the filling level of the oxygen cylinder from time to time.



7.6 Stop aspiration

1. Check the oxygen reserve at the contents pressure gauge of the pressure reducer.
2. Close the oxygen supply valve and wait until the system is depressurized.
3. Turn dial **5** to the left-hand stop (to “zero”). This prevents the pressure gauge being damaged by hammering when the device is switched back on.
4. Switch the module off using toggle switch **9**.
5. Clean and disinfect/sterilize the device and the device parts (see “11. Hygiene treatment” on page 39).
6. Then perform a function check (see “12. Function check” on page 42).

8. Interface MODULE

8.1 Coupling/oxygen connection function

The Interface MODULE allows oxygen (2.7 – 6 bar) to be tapped off or additional oxygen to be fed in from an external supply.

The Interface MODULE serves as an interface - to the central oxygen supply, for example. You can order it with different quick-fit couplings depending on your requirements.

The Interface MODULE has a pressure gauge of 0 - 10 bar to enable oxygen pressure to be monitored.

8.2 Operation


Making the connection

To tap off or feed in oxygen, plug the connector into external oxygen connector **8**. Push the connector far enough in for it to latch automatically.

Releasing the connection

To release the connector again, push the release collar towards the module.

Please note that this disconnection must be carried out directly at oxygen connection **8**.



9. CPAP MODULE

9.1 CPAP function

You can use the CPAP MODULE to perform CPAP therapy in conjunction with a CPAP valve approved by WEINMANN Emergency.

Conditions of use

Therapy may only be carried out on emergency patients who are breathing spontaneously.

In the event of respiratory failure, CPAP therapy is by no means adequate and artificial ventilation will be required here.

The patient is supplied with oxygen via a CPAP valve and a breathing mask.



Risk to patient!


Ensure that the free end of the CPAP valve is not covered or sealed off.

The patient must be able to breathe freely.

9.2 Operation

CPAP therapy

1. Slowly open the oxygen supply valve.
The contents pressure gauge indicates cylinder pressure.
2. Calculate remaining operating time (see "Calculating filling level" on page 43).



Method

1. Switch on the oxygen supply to the CPAP valve by switching toggle switch **4** to **I**.
2. If oxygen escapes from the O₂ outlet, switch it off by turning dial **5** to the left until you feel it reach the stop.
3. Connect the CPAP valve to the CPAP MODULE (see "4.7 Assembling the CPAP valve" on page 20).
4. Connect the CPAP valve to the breathing mask.
5. Put the breathing mask on the patient.
6. If the patient tolerates the breathing mask, attach it in position using the head band.
7. Increase CPAP pressure to a pressure of approx. 2 mbar by turning the regulator dial to the right.
8. Check that the breathing mask is properly located so it does not leak. Correct the position of the breathing mask if necessary.
9. Increase or reduce the flow of oxygen using the regulator dial until the desired CPAP therapy pressure is reached. To increase therapy acceptance, increase pressure slowly (approx. 1 mbar/ 30 seconds).
10. Check the position of the breathing mask again for leaks or for excessive pressure on the patient's face. Correct the position of the breathing mask if necessary.
11. Monitor the patient's therapy with the aid of the displays (CPAP MODULE and gas cylinder pressure gauges).

Stop CPAP therapy

1. Check the oxygen reserve at the contents pressure gauge of the pressure reducer.
2. Close the oxygen supply valve and wait until the system is depressurized.
3. Turn dial **5** anti-clockwise until you feel it reach the stop.


This will prevent the next patient inadvertently obtaining too high a CPAP pressure.

4. Switch off the CPAP MODULE using toggle switch **4**.
5. Take the breathing mask off the patient.
6. Clean and disinfect/sterilize the device and the device parts (see "11. Hygiene treatment" on page 39).
7. Perform a function check (see "12. Function check" on page 42).


10. OMNIVAC secretion aspiration system

The OMNIVAC secretion aspiration system consists of one or two aspirate bottles and the necessary tubing. The aspirate bottles are available in capacities of 250 ml, 500 ml or 1000 ml.


An overflow cutout in the lid of the bottle stops secretion penetrating the module by a ball floating on the surface of the secretion and blocking the outlet.




A tube which is connected to the tube stub of the aspirate bottle lid is provided for connection to the vacuum source.



We recommend fitting hydrophobic bacteria filter WM 22291 for the exhaust air to prevent secretion and bacteria penetrating the module. The filter is available as an accessory. It is a disposable item and must be replaced after every aspiration operation.




A large-lumen aspirating tube with a diameter of 10 mm and a tapered connection is connected for aspirating. This also functions as an aspiration intensifier, allowing even viscous and solid pieces of food to be removed quickly and easily from the mouth and throat. You are thus able to deal effectively with aspiration.



You can extend the large-lumen tube with an aspirating tube with a diameter of 6 mm to adapt aspiration catheters. This enables you to remove mucous and blood by the conventional method using aspirating catheters.

10.1 Starting work

Tip Cleaning will be facilitated if you pour about 50 ml of disinfectant or water into the aspirate bottle before you start. The aspirated matter is then less likely to adhere to the bottom of the bottle.



Important!

1. If necessary, adapt the end-piece of an aspirating catheter of a suitable size for tracheal or nasopharyngeal aspiration.
2. Switch on the vacuum source, e.g. the Suction MODULE, and set the desired vacuum if required.


For effective aspiration of viscous and solid pieces of food from the oral cavity, take the end-piece off the aspirating tube and use the aspirating tube on its own.

10.2 Aspiration



Pay attention during the aspiration process to ensure that no injuries are caused to the patient's oropharyngeal cavities, especially to the mucous membranes.

- You can briefly interrupt suction, for example if the skin is aspirated, by opening the fingertip regulator.



You can leave the fingertip regulator permanently open and hold it closed with a thumb. You then only need to lift your thumb briefly for venting.

Important! Please ensure that the aspirate bottles are always upright during operation, otherwise the ball of the overflow cutout cannot reliably block the connection to the vacuum source. This could result in secretion getting into the vacuum source. For hygiene reasons, we therefore recommend using hydrophobic bacteria filter WM 22291.

If the overflow cutout responds during the aspiration process before the full limit is reached, proceed as follows.

1. Briefly interrupt the aspiration process.
2. Switch off the vacuum source.
3. Keep the aspirate bottle upright (with its lid uppermost) and wait until the ball drops back down.
4. Continue with aspiration.

The aspirate bottle can be removed from the bracket to allow aspiration to be performed using the large-lumen tube.

Note Keep an eye on the fill level of the aspirate bottle during aspiration. Always empty the aspirate bottle as soon as the fill limit is reached. This will prevent the overflow cutout becoming contaminated and minimize cleaning effort.

The secretion is aspirated into the front aspirate bottle first.

When this aspirate bottle is full, it overflows into the second one. Once this bottle is full too, the overflow cutout stops aspiration continuing.

Emptying the aspirate bottle

When the aspirate bottle is full to the limit, you must interrupt the aspiration process and empty the aspirate bottle.

Important!

When taking off and emptying the aspirate bottle, please ensure that the lid does not accidentally come off the bottle and cause the contents to spill.

1. Take off the vacuum tube.
2. Take the aspirate bottle out of the bracket.
3. Carefully take off the lid of the aspirate bottle.
4. Empty the aspirate bottle.

Important!

Comply with the relevant regulations on disposal (see "3.1 Safety instructions" on page 8).

5. Push the aspirate bottle lid back on.
6. Put the aspirate bottle back into the bracket.
7. Reconnect the vacuum tube.
8. You can now continue aspirating.

10.3 Stop aspiration

When the aspiration process is complete, proceed as follows.

1. Switch off the vacuum source.
2. Empty the aspirate bottle (see "Emptying the aspirate bottle" on page 38).
3. Clean the OMNIVAC (see "11. Hygiene treatment" on page 39).

11. Hygiene treatment


The modules and the accessories used must be subjected to a hygiene treatment after every use.

After that, you should always perform a function check (see "12. Function check" on page 42).

11.1 Preparing the OMNIVAC secretion aspiration system


Note

When taking off and emptying aspirate bottles, please ensure that the lid does not accidentally come off an aspirate bottle and cause the contents to spill.



1. Take the tubes off the aspirate bottles and the module.


2. Take the aspirate bottles out of the holder.



3. Take off the aspirate bottle lid.

4. Empty the aspirate bottles.

Comply with the relevant regulations on disposal (see "3.1 Safety instructions" on page 8).



5. Remove the connectors and the ball from the overflow cutout in the aspirate bottle lids.

11.2 Cleaning, disinfecting and sterilizing

The individual parts can be cleaned, disinfected and sterilized as listed in the table below.

Follow the instructions for use for the disinfectant used. We recommend TERRALIN. It is recommended that suitable gloves (e.g. household or disposable gloves) are used for disinfecting.

Parts		Clean	Disinfect	Washing machine cycle	Sterilize		
Modules		Wipe down with a damp cloth	Disinfect by wiping	Not permitted			
Oxygen fittings		Clean cloth, possibly moistened with clean water	Not permitted				
OMNIVAC secretion aspiration system	Lid of aspirate bottles	In hot water with a mild household detergent	Immerse in dilute solution (1)	Not permitted			
	Ball of overflow cutout						
	Connectors						
	Aspirate bottles			Washing cycle up to 95 °C	Hot-steam sterilization up to 134 °C (2)		
	Aspirating tube						
	Intermediate tube						
	Vacuum tube						
	End-piece with fingertip regulator					Disposable items, re-use not permitted, replace for every patient	
	Bacteria filter						
Cannula/mask for inhalation, disposable							

Parts	Clean	Disinfect	Washing machine cycle	Sterilize
Mask for inhalation, reusable	In hot water with a mild household detergent	Immerse in dilute solution (1)	Washing cycle up to 95 °C	Hot-steam sterilization up to 134 °C (2)
CPAP valve	Disposable item, re-use not permitted, replace for every patient			

- (1) After disinfecting the parts, rinse them thoroughly in distilled water and then leave them to dry.
- (2) Hot steam sterilization at 134 °C in devices to EN 285, dwell time 5 minutes.

11.3 Assembling the OMNIVAC secretion aspiration system

Following the hygiene treatment, reassemble the parts in reverse sequence (see “11.1 Preparing the OMNIVAC secretion aspiration system” on page 39).

12. Function check

If you find any faults or deviations from specified values during the function check, you may not use the modules or OMNIVAC again until the faults have been remedied.

We recommend that you always keep in stock:

- seal for tube connection
and for inhalation connection WM 1145/31
- seal for plug connection WM 1145/68

12.1 Intervals

To ensure that you always have modules in perfect working order available, you should observe the following intervals.

Before every use

- Perform a function check (see following sections).

After every use

- Clean and disinfect/sterilize the device and the device parts (see "11. Hygiene treatment" on page 39).
- Perform a function check (see following sections).

At least every 6 months, if not used in between

- Perform a function check (see following sections).

12.2 Check filling

Open the oxygen supply valve **slowly**. You can now read off cylinder pressure at the pressure gauge of the pressure reducer. A display of 200 bar, for example, means that the cylinder is full, whilst at 100 bar, it is still half full.

You should ensure that you have a refill or reserve cylinder ready to guarantee the operational readiness of the device – for example, if the pressure gauge displays 50 bar or less.

Calculating filling level

Oxygen volume = cylinder volume x cylinder pressure.

	Cylinder volume	x cylinder pressure	= oxygen reserve
Example 1	10 l	x 200 bar	= 2000 l
Example 2	2 l	x 100 bar	= 200 l

Calculating operating time for oxygen inhalation

Example:

O₂ reserve = 1000 l; setting for O₂ inhalation 6 l/min:

$$\text{Operating time for inhalation (min)} = \frac{1000 \text{ l}}{6 \text{ l/min}} = 166 \text{ min} = 2 \text{ h } 46 \text{ min}$$

Calculating operating time for aspiration

Example:

O₂ reserve = 1000 l; consumption for aspiration 17 l/min (max.):

$$\text{Operating time for aspiration (min)} = \frac{1000 \text{ l}}{17 \text{ l/min}} = 58 \text{ min}$$

Calculating operating time for CPAP therapy

Example:

O₂ reserve = 1000 l; setting for CPAP 5 hPa = O₂-consumption of 20 l/min:

$$\text{Operating time for CPAP therapy (min)} = \frac{1000 \text{ l}}{20 \text{ l/min}} = 50 \text{ min}$$

Set CPAP therapy pressure [hPa]	Consumption with Boussignac CPAP valve for CPAP MODULE [l/min]
1	approx. 7,5
2	approx. 12
3	approx. 15
4	approx. 17.5
5	approx. 20
6	approx. 22.5
7	approx. 25
8	approx. 27.5
9	approx. 30
10	approx. 32.5

12.3 Test leaktightness

Important for CPAP MODULE!

Never seal the CPAP valve completely during operation. This may damage the pressure gauge.

1. Close the oxygen supply valve.
2. Switch on a module. This allows any residual oxygen to escape and depressurizes the system.
3. Switch the module off again.

4. Check that all screwed connections and tube connections are secure. Tighten up screwed connections **by hand** if necessary.
Under no circumstances may you tighten up the screwed connections with a spanner or other tools.
5. Open the oxygen supply valve **slowly**.
6. Close the valve again.
7. Watch the needle of the pressure gauge on the pressure reducer for approx. 1 minute.
If the needle position remains constant, the system is leaktight.
If the needle keeps dropping, there is a leak.

We recommend keeping replacement seals for the connections in stock.

Eliminating a leak

1. Prepare a solution of soap and water using unperfumed soap.
2. Use this solution to wet all connections, whether screwed, tube or plug connections. Bubbles will now form at the site of any leak.
3. Depressurize the system (shut off the oxygen supply, briefly switch on the module then switch it off again).
4. Replace the damaged sealing rings.
5. Then check for leaks again.

12.4 Checking inhalation

Required for Oxygen MODULE and Combi MODULE

1. Connect the inhalation mask to the threaded connection for inhalation.
2. Open the oxygen supply valve **slowly**.
3. Switch on the module.
4. Use the dial to set oxygen output to 6 l/min.

5. The oxygen must be felt to come out at the breathing station.
6. Switch off inhalation immediately afterwards to save oxygen.

12.5 Checking aspiration

Required for Suction MODULE and Combi MODULE

1. Open the oxygen supply valve **slowly**.
2. Switch on aspiration.
3. **Suction MODULE:** turn the dial to the right-hand stop. Take off the vacuum tube and hold vacuum connection **6** closed.

Combi MODULE: the vacuum is permanently set to ≥ -0.5 bar (at 4.5 bar O₂ inlet pressure) and cannot be read off directly on the pressure gauge. You should therefore plug WEINMANN Emergency test pressure gauge WM 15294 onto connection for the vacuum **6**.

4. Read off the value which becomes constant on the pressure gauge (Suction MODULE) or on the test pressure gauge (Combi MODULE). This value must be at least -0.5 bar at a feed pressure of 4.5 bar.
5. **Suction MODULE:** to check that the OMNIVAC secretion aspiration system is leaktight, connect the vacuum tube again and hold the aspiration opening of the end-piece closed instead.

Combi MODULE: to check that the OMNIVAC secretion aspiration system is leaktight, connect WEINMANN Emergency test pressure gauge WM 15294 to the end-piece of the fingertip regulator. Hold the fingertip regulator closed as you do so.

6. After no more than 30 seconds, at least -0.5 bar must be displayed.

If this value is not reached, the connections must be checked for leaks.


12.6 Checking oxygen flow

Required for the CPAP MODULE


1. Switch on the MODULE.
2. Use the dial to open the oxygen supply.
The oxygen must be felt to come out at the CPAP valve connection.
3. Switch off the oxygen supply immediately afterwards to save oxygen.

12.7 Testing the pressure gauge

Required for the CPAP MODULE



1. Plug the test set (WM 15665) onto pressure measurement tube connection **10**.
2. Crush the test set. Pressure on the pressure gauge must rise.



3. Kink the test set in the centre and hold in this position for about 5 seconds. Pressure may not drop continuously during this time.


13. Troubleshooting

Fault	Cause of fault	Remedy
Unusually high oxygen consumption	Leak in system	Find and eliminate leak (see "12.3 Test leaktightness" on page 44)
Module not working	Oxygen cylinder empty	Replace oxygen cylinder (see "4.2 Connecting oxygen supply" on page 14)
	Module incorrectly assembled	Check assembly (see "4.1 Assembling the modules" on page 13)
	Tube connections wrong way round	Check connections (see "4. Assembly" on page 13)
	Module defective	Have repaired
Inadequate vacuum or none at all	Leak in system	Eliminate leak (see "12.3 Test leaktightness" on page 44)
	Bacteria filter blocked (e.g. due to moisture)	Change filter; if necessary, take out and complete aspiration without filter
	Module defective or contaminated inside	Have repaired
Inadequate O ₂ output during inhalation	Leak in system	Eliminate leak (see "12.3 Test leaktightness" on page 44)
	Module defective or contaminated inside	Have repaired
Noises when vacuum generated	Spring in nonreturn valve vibrating	Not required, as function not impaired
Noises during CPAP therapy	Required for function	No remedy required
CPAP valve failing to build up any pressure	Connections wrong way round	Check tubes and free of kinks if necessary
	Leaks, kinks in tubes	
CPAP pressure does not change	Tubes kinked or blocked	Check tubes and free of kinks if necessary

Fault	Cause of fault	Remedy
Needle of pressure gauge not at zero	Pressure gauge needs adjusting	Adjust pressure gauge needle (see following section)

13.1 Adjusting pressure gauge

If the needle of the pressure gauge does not show zero when at rest (device switched off and oxygen cylinder connected), perform the steps which follow.



1. Carefully lever out the plastic cover of the adjusting screw.
2. Adjust the needle using the adjusting screw. Use a small screwdriver (e.g. a watchmaker's screwdriver) to do this.
3. Put the plastic cover back on.

14. Servicing

14.1 Intervals

Every 4 years

- Manufacturer, or professionals expressly authorized by the manufacturer, to service oxygen fittings (e.g. pressure reducer).
- Manufacturer, or professionals expressly authorized by the manufacturer, to service modules.

Every 10 years

- Repeat test by TÜV of conventional oxygen cylinders made of steel and aluminum. You can read off the test date from the shoulder of the cylinder.

14.2 Scope of servicing

Note

Remember that a final check needs to be performed after any repair.

We recommend having maintenance measures such as servicing or repair work carried out by the manufacturer, WEINMANN Emergency, or by professionals expressly authorized by the manufacturer to do this.

The devices should be serviced every 4 years. The device should be cleaned and disinfected beforehand (see "11. Hygiene treatment" on page 39).

Take the following into account.

- Visual inspection:
 - mechanical damage
 - labeling of components
- Accuracy of the pressure display
- Leaktightness of system
- Oxygen output and aspiration performance
- Replace wear parts, compulsory change parts.

You should also check intervals for the regular function check (see “12. Function check” on page 42).

14.3 Disposal

Do not dispose of the device in domestic waste. To dispose of the device properly, contact a licensed, certified disposal company. You can obtain the address from your Environment Officer or your local authority. The device packaging (cardboard and inserts) can be disposed of in paper recycling facilities.

15. Scope of supply

15.1 Standard scope of supply

1. Oxygen MODULE	WM	22200
consisting of:		
– module for oxygen inhalation		
– instructions for use	WM	16201
– set of assembly elements	WM	15288
– connecting bushing with union nut		
– G 3/8 (up to year of manufacture 2009)	WM	1470
– UNF (from year of manufacture 2010)	WM	31122
2. Oxygen MODULE with angled connecting bushing	WM	22360
consisting of:		
– module for oxygen inhalation		
– instructions for use	WM	16201
– set of assembly elements	WM	15288
– angled connecting bushing with union nut		
– G 3/8 (up to year of manufacture 2009)	WM	22319
– UNF (from year of manufacture 2010)	WM	31130
3. Suction MODULE	WM	22220
consisting of:		
– module for vacuum		
– instructions for use	WM	16201
– set of assembly elements	WM	15288
4. Combi MODULE	WM	22210
consisting of:		
– module for oxygen inhalation and for vacuum		
– instructions for use	WM	16201
– set of assembly elements	WM	15288
– connecting bushing with union nut		
– G 3/8 (up to year of manufacture 2009)	WM	1470

– UNF (from year of manufacture 2010)	WM	31122
– test pressure gauge set for vacuum	WM	15294
5. Combi MODULE with angled connecting bushing	WM	22370
consisting of:		
– module for oxygen inhalation and for vacuum		
– instructions for use	WM	16201
– set of assembly elements	WM	15288
– angled connecting bushing with union nut		
– G 3/8 (up to year of manufacture 2009)	WM	22319
– connecting bushing with union nut, angled at 90°, ∅ 6 mm, UNF 9/16	WM	29140
– test pressure gauge set for vacuum	WM	15294
6. Interface MODULE	WM	22230
consisting of:		
– module with DIN coupling for central gas system with pressure display		
– instructions for use	WM	16201
– set of assembly elements	WM	15288
7. CPAP MODULE	WM	29100
consisting of:		
– CPAP module with Walther coupling	WM	29105
– instructions for use	WM	16201
– connecting bushing with union nut, angled at 90°, ∅ 6 mm, UNF 9/16	WM	29140
– assembly set	WM	15288
– Boussignac CPAP valve for CPAP MODULE, disposable, 10x	WM	15638
– 2x CPAP/NIV disposable silicone mask, size S (child), incl. retaining ring for attaching to head	WM	20703
– 4x CPAP/NIV disposable silicone mask, size M (adult), incl. retaining ring for attaching to head	WM	20704
– 4x CPAP/NIV disposable silicone mask, size L (large adult), incl. retaining ring for attaching to head	WM	20705
– silicone head attachment	WM	20702
– pressure gauge test set	WM	15665
– sign, O ₂ consumption	WM	76300

8. CPAP MODULE	WM	29125
consisting of:		
– CPAP module with Walther coupling	WM	29105
– instructions for use	WM	16201
– connecting bushing with union nut 9/16 UNF, angled at 90°	WM	31130
– assembly set	WM	15288
– Boussignac CPAP valve for CPAP MODULE, disposable, individual part		
– CPAP/NIV disposable silicone mask, size M (adult), incl. retaining ring for attaching to head	WM	20704
– silicone head attachment	WM	20702
– pressure gauge test set	WM	15665
– sign, O ₂ consumption	WM	76300

15.2 Accessories

1. Oxygen cylinder, 2 liter	WM	1822
2. Lightweight aluminum oxygen cylinder, 2 liter	WM	1814
3. WEINMANN Emergency pressure reducer	WM	30301
4. WEINMANN Emergency pressure reducer with inhalation option	WM	30851
5. WEINMANN Emergency pressure tube for 10 bar, with connecting bushing and union nut G 3/8, on the other side optionally union nut G 3/8 or connector for oxygen supply		
6. Set for permanently fitting a module	WM	15197
7. Supplementary set for permanently fitting another module	WM	15199
8. Connector DIN 13260 – S – O ₂	WM	2057
9. Adapter M 12x1 – G3/8 for connecting a pressure tube	WM	22265

Accessories for vacuum

1. Test pressure gauge set for vacuum	WM	15294
2. OMNIVAC secretion aspiration system 500 ml	WM	2260

3. Bracket for aspirate bottle	WM	2245
4. Set of bacteria filters, 1x	WM	22291
5. Set of bacteria filters, 10x	WM	15237
6. Set of bacteria filters, 50x	WM	15238
7. Aspiration catheter CH 6, Ø 2 mm	WM	5156
8. Aspiration catheter CH 10, Ø 3 mm	WM	5158
9. Aspiration catheter CH 12, Ø 4 mm	WM	5159

Accessories for inhalation

1. Bubble humidifier	WM	13790
2. Nasal cannula without ear-hooks	WM	1925
3. Nasal cannula with ear-hooks	WM	1929
4. Insufflation catheter	WM	1922
5. Inhalation mask with ventilating bag	WM	1422
6. Inhalation mask	WM	1429

Accessories for CPAP

1. CPAP/NIV disposable silicone mask, size S (child), incl. retaining ring for attaching to head	WM	20703
2. CPAP/NIV disposable silicone mask, size M (adult), incl. retaining ring for attaching to head	WM	20704
3. CPAP/NIV disposable silicone mask, size L (large adult), incl. retaining ring for attaching to head	WM	20705
4. CPAP/NIV reusable silicone mask, size S (child)	WM	20713
5. CPAP/NIV reusable silicone mask, size M (adult)	WM	20714
6. CPAP/NIV reusable silicone mask, size L (large adult)	WM	20715
7. Set of disposable masks (one each of disposable CPAP/NIV mask in sizes S, M and L), each incl. retaining ring for attaching to head	WM	15807

8. Set of reusable masks (one each of CPAP/NIV disposable mask in sizes S, M and L)	WM	15808
9. Boussignac CPAP valve for CPAP MODULE, disposable, 10x	WM	15638
10. Silicone head attachment	WM	20702
11. Retaining ring for head attachment	WM	20701
12. Pressure gauge test set	WM	15665

15.3 Replacement parts

1. Seal for WEINMANN Emergency tube	WM	1145/31
2. Seal for plug connection	WM	1145/68
3. Blind plug for housing	WM	22229
4. Protective ring for plug connection	WM	1145/84
5. Connecting bushing with union nut 5.2 mm	WM	1470
6. Set of assembly elements	WM	15288
7. Cap for plug connection	WM	22204
8. End-piece with fingertip regulator and plug	WM	2251
9. Ball for overflow cutout for OMNIVAC	WM	2279
10. Connecting bushing 9/16 UNF for Oxygen, Combi MODULE	WM	31122
11. Connecting bushing mit union nut 9/16 UNF, 90° angle		
– for CPAP MODULE	WM	29140
– for Oxygen, Combi MODULE	WM	31130

16. Technical data

	Oxygen MODULE	Suction MODULE	Combi MODULE	Interface MODULE	CPAP MODULE
Dimensions W x H x D in mm	100 x 130 x 90			100 x 172 x 90	100 x 145 x 90
Weight	0.9 kg	0.9 kg	0.95 kg	0.65 kg	0.9 kg
Temperature range – operation – storage	–18 °C to +60 °C –40 °C to +70 °C				
Operating gas	Medical oxygen				
Operating pressure	2.7 – 6 bar possible, recommended: 4.5 bar				
Req. gas quantity	≥ 80 l/min O ₂				
Compressed gas connection	External thread G3/8; NIST adapter available on request				
Oxygen output	Infinitely adjustable from 0 to 15 l/min		Infinitely adjustable from 0 to 15 l/min		Infinitely adjustable from 0 to approx. 43 l/min
Tolerance range	At 0–3.9 l/min ±15 % At 4–15 l/min ±10 %		At 0–3.9 l/min ±15 % At 4–15 l/min ±10 %		
Maximum CPAP (at feed pressure 4.5 bar, ambient conditions 1013 hPa/ 21 °C)					Approx. 15 ±3 hPa*
Class to 93/42/EEC	IIa				
Classification to EN ISO 10079-3		Medium vacuum			
Accuracy of pressure display	Class 1.6				
Flow outlet	9/16-UNF		9/16-UNF	DIN coupling	9/16-UNF
Standards applied	EN 1789				

CE 0197

* If ambient conditions and feed pressures differ from these, the specified performance data may also deviate.


The right to make design modifications is reserved.

16.1 Determining oxygen concentration

Oxygen and Combi MODULES

Oxygen concentration depends on the flow rate of the oxygen and on the patient's respiratory minute volume.

You can determine the relevant reference values from the diagram below.



Example

Set flow rate is 6 l/min, respiratory minute volume is 10 l/min, breathing station with economy bag in use;
from this information, the above-mentioned diagram produces an oxygen concentration of approx. 65 %.


CPAP MODULE

Oxygen concentration depends on the following factors:


- respiratory frequency
- tidal volume
- CPAP

The corresponding reference values can be determined from the diagrams below.


CPAP = 5 hPa



CPAP = 7.5 hPa




CPAP = 10 hPa



16.2 External oxygen output

The following outputs apply to oxygen output for other devices.




Interface MODULE

Inlet	Oxygen output
2.7 bar dynamic back pressure at 80 l/min	min. 70 l/min
of WEINMANN Emergency pressure reducer WM 1102/106	min. 100 l/min
of WEINMANN Emergency pressure reducer WM 30301	min. 90 l/min

Several modules

If several modules are switched in series, output falls the further the relevant module is from the oxygen feed. This is due to the increased flow resistance when oxygen is passed through several modules.

The values quoted relate to the fact that oxygen is only output by one module at a time.



Inlet	Oxygen output		
	A	B	C
2.7 bar dynamic back pressure at 80 l/min	min. 76 l/min	min. 73 l/min	min. 70 l/min
of WEINMANN Emergency pressure reducer WM 1102/106	min. 100 l/min	min. 95 l/min	min. 90 l/min
of WEINMANN Emergency pressure reducer WM 30301	min. 91 l/min	min. 88 l/min	min. 85 l/min

16.3 Oxygen output, inhalation

Inlet pressure in operation	2.7 bar	3.0 bar	3.5 bar	6.0 bar
Max. O₂ output	11 l/min	12 l/min	15 l/min	15 l/min

Tolerance $\pm 10\%$

16.4 Aspiration performance

Maximum performance

Maximum performance for the Combi MODULE and the Suction MODULE depend on the inlet pressure of the oxygen supply in operation. The measurements relate to an aspirate bottle with a capacity of 2 liters.

Inlet pressure p₂	Max. vacuum	Max. aspiration performance	O₂ consumption
2.7 bar	- 0.40 bar	8.4 l/min	9.3 l/min
3.0 bar	- 0.44 bar	8.6 l/min	10.1 l/min
3.5 bar	- 0.53 bar	8.8 l/min	11.4 l/min
4.0 bar	- 0.58 bar	9.0 l/min	12.2 l/min
4.5 bar	- 0.60 bar	9.0 l/min	14.0 l/min
5.0 bar	- 0.60 bar	9.0 l/min	15.0 l/min
5.5 bar	- 0.60 bar	8.7 l/min	17.0 l/min
6.0 bar	- 0.60 bar	8.5 l/min	19.0 l/min

Tolerance $\pm 10\%$. If the bacteria filter is used, aspiration performance is reduced as a function of humidity by approx. 1 to 3 l/min.

Suction MODULE aspiration performance

The aspiration performance of the Suction MODULE at any particular time depends on the vacuum set. The measurements relate to an aspirate bottle with a capacity of 2 liters.

Vacuum set	Aspiration performance	O ₂ consumption	Required inlet pressure p ₂
- 0.2 bar	5.3 l/min	6.5 l/min	2.7 – 6 bar
- 0.3 bar	6.5 l/min	7.7 l/min	2.7 – 6 bar
- 0.4 bar	8.4 l/min	9.3 l/min	2.7 – 6 bar
- 0.5 bar	8.3 l/min	10.5 l/min	3.5 – 6 bar
- 0.6 bar	9.0 l/min	14.0 l/min	4.5 bar

Tolerance $\pm 10\%$. If the bacteria filter is used, aspiration performance is reduced by approx. 1 to 3 l/min.

17. Warranty

WEINMANN Emergency gives the customer a limited manufacturer warranty on new original WEINMANN Emergency products and any replacement part fitted by WEINMANN Emergency in accordance with the warranty conditions applicable to the product in question and in accordance with the warranty periods from date of purchase as listed below. The warranty conditions can be downloaded from www.weinmann-emergency.com on the Internet. We can also send you the warranty conditions on request.

In the event of a claim under warranty, contact your specialist dealer.

Product	Warranty period
WEINMANN Emergency devices including accessories (except masks) for oxygen medicine and emergency medicine	2 years
Masks including accessories, rechargeable batteries, batteries (unless quoted differently in the technical documentation), sensors, tube systems	6 months
Disposable products	None

18. Declaration of conformity

WEINMANN Emergency Medical Technology GmbH + Co. KG declares herewith that the product complies fully with the respective regulations of the Medical Device Directive 93/42/EEC. The unabridged text of the Declaration of Conformity can be found on our website at www.weinmann-emergency.com

Manufacturer

WEINMANN Emergency
Medical Technology GmbH + Co. KG
Frohbösestraße 12
22525 Hamburg
GERMANY
T: +49 40 88 18 96-120
E: customerservice@weinmann-emt.de

Center for Production, Logistics, Service

WEINMANN Emergency
Medical Technology GmbH + Co. KG
Siebenstücken 14
24558 Henstedt-Ulzburg
GERMANY

CE 0197