

EUROHEATER 2D

A compact 2 kW tactical air heater designed to provide reliable heating for smaller shelters, command posts, and mobile field operations. Built for portability and durability, it delivers dependable heat in a rugged, self-contained system.



Tents



Bunkers & trenches



Vehicles



Communication



IFV & APCs

ABOUT

Developed for users who need a lightweight and practical heating solution, the Euroheater 2D combines robust construction with simple operation. The unit is housed in a water-repellent Nanuk case and operated through a sealed control panel.

Designed for 12 V operation, the heater must be connected to a compatible battery system such as Flexibatt, making it well suited for mobile and off-grid use.

The system features an isolated combustion chamber that ensures clean, breathable air while maintaining safe and efficient operation. In addition to heating, the unit can also operate in ventilation mode to supply fresh outside air without activating the heating function.

Item No. EH-000

Heat Capacity (Low-High)	1–2 kW (3.400–6.800 BTU/h)	Air Flow, CFM (Low-High)	34–75 m³/h
Fuel Type	Diesel/Kerosene/F34/JP8/HVO	Decibel (Max.)	60 dB
Fuel Consumption	0.10–0.24 l/h	Weight	13 kg
Fuel Tank Capacity	7.5 liter	Dimensions (L x W x H)	550 x 295 x 410 mm
Rated Voltage	12V DC	Cables (Prysmian Group Carol)	-40 °C, UV-resistant, oil-resistant
Ambient Air Temperature	+20 to -45°C	Connectors	Nanuk
Max. Altitude	5.400 meter	Heater (Autoterm)	2D Diesel Air Heater
Power Consumption (Low-High)	10–29 W (0.8–2.42 A)	Certification	CE

